

FIG. 1

10




FIG. 2

AUDIO  
DEVICE  
34  
(MEMBER  
USER AGENT)  
18A'

USER A  
(COMPOSITE  
USER AGENT)  
20A

USER Z  
(VIA SIP  
PROXY 14)  
18




FIG. 3




FIG. 4




FIG. 5





FIG. 6

**FIG. 7**